



**SMART
VALVE**

BRAINS FOR YOUR WATER METER™

INSTALLATION and ADJUSTMENT INSTRUCTIONS

Congratulations on your purchase of the Smart Valve™. You are about to start saving!
Installation should only be done by a licensed plumber or Mechanical Engineer.



Install after water meter and before pressure reducer or booster pump. Soon after the backflow preventer is usually a good place.



FLANGED SMART VALVE

1. Identify installation location and prepare pipe for installation on the user side of the water meter. Install location should be before any other fixtures or devices such as a pressure reducer or booster pump. Immediately after the backflow preventer is often a good place.
2. It is recommended wherever possible (but not critical) to have 10 diameters of straight pipe before and after the valve to ensure there are no turbulence issues. I.e.: 2" valve x 10 dia. = 20" before and after. If you must choose, leave more straight pipe before the valve.
3. Prepare pipe flange spacing to allow for length of valve and gaskets to be installing inline. Valve length varies by size, please see Cut Sheets for exact dimensions.
4. Install using flange gaskets (usually 150 pound gasket) at each flange joint.
5. Make sure the closed orifice end faces upstream and the open orifice end faces downstream. See flow direction arrow on the valve.
6. Slowly turn water supply back on. Vent trapped air from the water line where possible. Flow may be turbulent until excess air is out of the system.



**SMART
VALVE™**

BRAINS FOR YOUR WATER METER™

ADJUSTMENT INSTRUCTIONS

The Smart Valve is an EXTERNALLY ADJUSTABLE device, allowing you to fine tune the spring setting for maximum savings without any negative effects, and to allow you to adjust to any future changes in your water system pressure or flow rate.

Installing a pressure gauge (temporary or permanent) at least a few feet downstream of the Smart Valve will greatly assist in calibrating the valve with your water system, but is not mandatory.

Your goal is to adjust the Smart Valve to the strongest setting tolerable to the system without causing problems or complaints due to too large of a pressure drop. The stronger the setting the more you will save in meter accuracy and water over-consumption.

Once the valve has been properly installed, locate the ‘adjustment windows’ near the center of the valve. Inside are numerous slots designed to fit the adjustment tool. **Attach the tool to a 1/2" head ratchet handle.** You will insert the adjustment tool pin into one of the slots and rotate the inner collar in either the PLUS (+) or MINUS (-) direction as marked on the valve.

The Smart Valve is delivered to you near the full MINUS setting where there should be little to no effect from the valve. Insert the pin into a slot in the window and rotate the inner collar towards the PLUS side. Each full length of window adjustment is a ‘click’.

Each click towards the PLUS side will further increase the backpressure upstream towards the water meter, and should result in a corresponding pressure drop of 1-2 PSI downstream of the valve. There are approximately 22-23 clicks between full MINUS and full PLUS.

If an adjustment needs to be made after the Smart Valve has been in operation for some time, you might experience ‘sticktion’, where it seems the inner collar is ‘stuck’ and the first adjustment will be more difficult. Once you break the ‘sticktion’ with a little extra force the valve will be easier to adjust.

